

STARTER RELAY

**ATR 102****12 VOLT**

Starter Relay

Use for : Starter / Grow plug system

Contact current Max : 100 Amp.

Time operate 60 seconds

Coil voltage 12 volt

**ATR 104****24 VOLT**

Starter Relay

Use for : Starter / Grow plug system

Contact current Max : 100 Amp.

Time operate 60 seconds

Coil voltage 24 volt